




FLAG WITH SNOW DEPTH GAUGE

M-220 1807 GB




Flag on anchor loop with integrated flag mount

Place the flag into the flag mount and adjust the snow depth gauge to the desired position.



Flag on bracket without flag mount

Install the flag in a suitable location and move the snow depth gauge to the desired position.



cwlundberg.com

A= Snow depth gauge B= Locking plate C= Self-tapping stainless steel screw with a sealing washer